



# Stair Rail Splice Instructions

**IMPORTANT:** Before starting your ProBuilt Railing project, please ensure to check your local building codes and building permit requirements prior to installation. Building codes may vary. Always comply with all applicable building codes. Please check areas to be drilled are free from utilities, services and hazards. No member of BW Creative Wood Industries or the Dealer shall be liable for any loss or damage resulting from the improper installation or use of this product. If any member of BW Creative Wood Industries or the Dealer becomes liable for any loss or damage, the aggregate liability of BW Creative Wood Industries company shall be limited to the retail purchase price of that product. For further information, please consult your authorized ProBuilt Dealer.

**Failure to follow these instructions could result in serious injury or death!**

